









## OFFSETS



### Store Point

Point ID: 14

Description: MH Enter description

Northing: 5523061.81m


Easting: 311567.168m

Elevation: 380.593m

Note: Tap to enter note

Review Measurement Advanced GIS Attributes

☒ Pnt ☐ Cancel



### Point Database

Point ID	Elevation	Description
3	384.610m	KERB
4	381.472m	
5	384.610m	
6	382.221m	
7	382.123m	HOI
8	381.793m	HOI
9	381.621m	HOI
10	381.407m	HOI
11	381.318m	HOI
12	381.411m	HOI
13	381.441m	HOI
14	380.593m	MH

Two points are logged with 1.2m level difference

Edit Delete Add Find

### POINT OFFSET

PDOP: 2.2

Antenna: 1.800m

RTK Fixed

6m

Next ID: 7

<No Desc>

### GNSS Measurement Modes

Standard Measurement Offset Measurement

Auto Record Points Local Transformation Point

Check Point

Add Invert

Go Back

### Trilateration

Observation Baseline

Point 1: [Dbl Click]

Point 2: [Dbl Click]

Switch Side Save Point Map View

New Pnt	Pnt 1 Dist	Pnt 2 Dist	S

Measure From Pnt1 Measure From Pnt2 Close

### Add Trilateration Point

Point ID: 7

Description: No Desc

Baseline Side: ☐ Left ☒ Right

Enter the Point ID of the new point and a description

☒ ☐ Cancel

### Trilateration

Observation Baseline

Point 1: [Redacted]

Point 2: [Dbl Click]

Add Point Switch Side Save Point Map View

New Pnt	Pnt 1 Dist	Pnt 2 Dist	S

Measure From Pnt1 Measure From Pnt2 Close

### Trilateration

Observation Baseline

Point 1: [Redacted]

Point 2: [Dbl Click]

Add Point Switch Side Save Point Map View

Key Pad Entry

Point Select - Map

Point Select - List

Point Select - New

Cancel

New Pnt	Pnt 1 Dist	Pnt 2 Dist	S
7			

Measure From Pnt1 Measure From Pnt2 Close

